


エアーマスク3 / 4 / 5 / 6の取り付け方 How to Fix Air Mask 3 / Air Mask 4 / Air Mask 5 / Air Mask 6



Japanese

エアーマスク3 / 4 / 5 / 6は、シールド内部に呼吸がこもることを防ぎ、またヘルメット外部へ効率良く呼吸を排出することで、シールドの曇り防止に効果を発揮します。

- エアーマスク3 / 4 / 5 / 6の、エアーマスク本体は同一ですが、付属の取り付け用面ファスナーの形状が異なり、**エアーマスク3はX-Eleven / X-9用、エアーマスク4はX-TWELVE用、エアーマスク5はX-Fourteen用、エアーマスク6はX-SPR Pro/X-Fifteen用となります。**
- 取り付けは、チークパッドを外した状態で行ってください。エアーマスクと同梱されている面ファスナー裏の保護フィルムを剥がし、ヘルメット内部の形状に添って貼ります(図A)。面ファスナーを貼る部分に付着しているほこりや油分は、面ファスナーを貼り付ける前にきれいにふき取ってください。エアーマスク5 / 6は、別添えのスペーサーの裏表を確認して、エアーマスク本体に図Dのように装着して下さい。
- ヘルメットに貼り付けた面ファスナーに、エアーマスク本体を取り付けます。
- 取り付け後、ヘルメットを被ってエアーマスクが顔に密着するか確認してください。顔に密着していない場合、エアーマスク本体を上下左右にずらして(図B、C)、位置を調整してください。

English

Air Masks 3, 4, 5, and 6 prevent fogging of a shield / visor preventing expiration to stay inside a shield / visor and exhausting it effectively.

- Although the main component is same for Air Masks 3, 4, 5, and 6, the shape of the hook-and-loop fastener is different. **Air Mask 3 is for X-Eleven, X-Spirit and X-9, Air Mask 4 is for X-TWELVE and X-Spirit II, Air Mask 5 is for X-Fourteen and X-Spirit III, and Air Mask 6 is for X-SPR Pro and X-Fifteen.**
- Remove cheek pads before fixing Air Masks 3, 4, 5, and 6. Peel off a protection film of a hook-and-loop fastener and stick it as per Drawing A. Clean a surface of a portion of a helmet where to stick a fastener before sticking. For Air Masks 5 and 6, fix a spacer to an Air Mask as per Drawing D.
- Then, fix an Air Mask to a hook-and-loop fastener.
- Once an Air Mask has been fixed, put the helmet on and make sure that an Air Mask fits closely to your face. In case it does not fit closely, adjust its position as per Drawing B and C.